

APPARTAMENTO APPARTAMENTO TCA

IT - MACCHINA DA CAFFÈ PER USO DOMESTICO

Manuale uso e manutenzione

Istruzioni originali

EN - COFFEE MACHINE FOR DOMESTIC USE

User and maintenance manual

Translation of the original instructions

FR - MACHINE À CAFÉ À USAGE DOMESTIQUE

Manuel d'utilisation et d'entretien

Traduction des instructions originales

DE - KAFFEEMASCHINE FÜR DEN HAUSGEBRAUCH

Bedienungs- und Wartungsanleitung

Übersetzung der Originalanleitungen

ES - MÁQUINA DE CAFÉ PARA USO DOMÉSTICO


Manual de uso y mantenimiento

Traducción de las instrucciones originales

PT - MÁQUINA DE CAFÉ PARA USO DOMÉSTICO

Manual de uso e manutenção

Tradução das instruções originais



ROCKET®

ESPRESSO MILANO

APPARTAMENTO

IT Congratulazioni per la scelta della macchina da caffè espresso APPARTAMENTO

Si tratta di un prodotto realizzato con lo scopo di soddisfare la tua esigenza per un'ottima qualità in tazza per le bevande a base di caffè.

Leggere attentamente le istruzioni per un corretto funzionamento della macchina.

Questo manuale fornisce importanti linee guida per uso, manutenzione e un'installazione sicura.

Contiene inoltre utili consigli che consentiranno di sfruttare al meglio le potenzialità della macchina APPARTAMENTO.

EN Congratulations on choosing the APPARTAMENTO espresso coffee machine.

This product is designed to satisfy your need for exquisite quality in cups of coffee-based beverages.

Carefully read the instructions to operate the machine correctly.

This manual provides important guidelines for use, maintenance and safe installation.

It also contains useful recommendations that will allow you to maximise the potential of the APPARTAMENTO machine.

FR Félicitations pour avoir choisi la machine à café expresso APPARTAMENTO.

C'est un produit conçu dans le but de satisfaire le besoin d'une excellente qualité dans la tasse pour les boissons à base de café.

Lire attentivement les instructions pour un fonctionnement correct de la machine.

Ce manuel fournit des directives importantes pour l'utilisation, l'entretien et l'installation de la machine en toute sécurité.

Il contient également des conseils utiles qui permettront d'exploiter au mieux le potentiel de la machine APPARTAMENTO.

DE Wir gratulieren Ihnen zu Ihrer Wahl der Espressomaschine APPARTAMENTO.

Es handelt sich um ein Produkt, das speziell für eine hervorragende Qualität für Kaffeegetränke in der Tasse entwickelt wurde.

Bitte lesen Sie die Anweisungen sorgfältig durch, um einen korrekten Betrieb der Maschine zu gewährleisten.

Dieses Handbuch enthält wichtige Anleitungen zur Verwendung, Wartung und sicheren Installation.

Außerdem enthält es nützliche Tipps, die Ihnen helfen, das Beste aus Ihrer APPARTAMENTO-Maschine herauszuholen.

ES Enhorabuena por haber elegido la máquina de café expresso APPARTAMENTO.

Se trata de un producto realizado a fin de satisfacer las exigencias referentes a una taza de bebida a base de café de excelente calidad.

Lea atentamente las instrucciones para utilizar la máquina correctamente.

Este manual proporciona directrices importantes para el uso, el mantenimiento y una instalación segura.

Además, incluye consejos útiles para que aproveche al máximo el potencial de la máquina APPARTAMENTO.

PT Parabéns pela escolha da máquina de café expresso APPARTAMENTO.

É um produto feito com o objetivo de satisfazer a necessidade de excelente qualidade na chávena para as bebidas à base de café.

Leia as instruções cuidadosamente para o correto funcionamento da máquina.

Este manual fornece orientações importantes para o uso, a manutenção e a instalação segura. Ele também contém dicas úteis que lhe permitirão aproveitar ao máximo o potencial da máquina APPARTAMENTO.

IT - MACCHINA DA CAFFÈ PER USO DOMESTICO	6-37
EN - COFFEE MACHINE FOR DOMESTIC USE	38-69
FR - MACHINE À CAFÉ À USAGE DOMESTIQUE	70-101
DE - KAFFEEMASCHINE FÜR DEN HAUSGEBRAUCH	102-133
ES - MÁQUINA DE CAFÉ PARA USO DOMÉSTICO	134-165
PT - MÁQUINA DE CAFÉ PARA USO DOMÉSTICO	166-197



**DICHIARAZIONE DI CONFORMITÀ CE - EC DECLARATION OF CONFORMITY
 DÉCLARATION DE CONFORMITÉ CE - EG-KONFORMITÄTSERKLÄRUNG
 DECLARACIÓN DE CONFORMIDAD CE - DECLARAÇÃO DE CONFORMIDADE CE**

Rocket Milano srl
 Via E. Curiel 13
 20060 LISCATE (MI)
 ITALY

- come costruttore di MACCHINE PER CAFFÈ, dichiara che il prodotto:
- being the manufacturer of COFFEE MACHINES, hereby declares that the product:
- en tant que constructeur de MACHINES A CAFE, déclare que le produit:
- erklärt als Hersteller von KAFFEEMASCHINEN, daß das Gerät:
- como fabricante de CAFETERAS, declara que el producto:
- como fabricante de MÁQUINAS DE CAFÉ, declara que a máquina:

Modello - Model - Modell - Modelo: APPARTAMENTO - APPARTAMENTO TCA

- al quale si riferisce questa dichiarazione è conforme ai requisiti essenziali applicabili delle seguenti DIRETTIVE e REGOLAMENTI e successive modifiche e integrazioni:
- to which this declaration refers, complies with the applicable essential requirements of the following DIRECTIVES and REGULATIONS and subsequent amendments:
- auquel se réfère cette déclaration est conforme aux exigences essentielles applicables des DIRECTIVES et RÈGLEMENTS et modifications et ajouts successifs:
- auf welches sich diese Erklärung bezieht, gemäß den folgenden EG-Vorschriften gebaut ist VORSCHRIFTEN und REGELUNGEN sowie nachfolgenden Änderungen und Ergänzungen:
- al que se refiere esta declaración es conforme con los requisitos esenciales aplicables de las siguientes DIRECTIVAS y REGLAMENTOS y siguientes modificaciones y correcciones:
- referida nesta declaração, é conforme com os requisitos essenciais aplicáveis das seguintes DIRECTIVAS e REGULAMENTOS e sucessivas modificações e integrações:

- 2014/68/UE** - Direttiva attrezzature a pressione (PED) con applicata l'esclusione al Capitolo 1 Article 1 Par. 2 (f)
 - Directive of pressure equipment (PED) with applied the exclusion to Chapter 1 Article 1 Par. 2 (f)
 - Directive sur les équipements sous pression (PED) avec exclusion appliquée au Chapitre 1 Article 1 Par. 2 (f)
 - Richtlinie über die Bereitstellung von Druckgeräten (PED) mit angewandtem Ausschluss von Kapitel 1 Artikel 1 Abs. 2 (f)
 - Directiva sobre equipos a presión (PED) con exclusión aplicada al Capítulo 1 Artículo 1 Par. 2 (f)
 - Diretiva de equipamento sob pressão (PED) com a exclusão aplicada ao Capítulo 1 Artigo 1 Par. 2 (f)

- 2014/30/UE** Direttiva compatibilità elettromagnetica EMC - Electromagnetic compatibility EMC Directive - Directive de compatibilité électromagnétique EMC - Richtlinie elektromagnetische Verträglichkeit EMV - Directiva compatibilidad electromagnética EMC - Directiva sobre a compatibilidade electromagnética EMC

- 2014/35/UE** Direttiva bassa tensione - Low voltage Directive - Directive de basse tension - Niederspannungsrichtlinie - Directiva baja tensión - Directiva sobre baixa tensão

- 2012/19/UE** Direttiva RAEE - WEEE Directive - Directive DEEE - Directiva RAEE - Directiva RAEE

- 2011/65/UE** Direttiva RoHS - RoHS Directive - Directive RoHS - RoHS-Richtlinie - Directiva RoHS

- 1935/2004/EU** - Regolamento sui materiali a contatto con i prodotti alimentari
 - Regulation on food contact materials
 - Règlement sur les matériaux en contact avec les denrées alimentaires
 - Regelung für Materialien, die mit Lebensmitteln in Kontakt kommen
 - Reglamentos sobre los materiales en contacto con los productos alimenticios
 - Regulamento sobre materiais em contacto com os produtos alimentares

- in conformità alle norme - gemäß den Vorsch
 - in compliance with standards - en conformidad de las normas
 - en conformité avec les normes - em conformidade com as normas

EN 60335-1:2012 / AC:2014 / A11:2014 / A13:2017 / A1:2019 / A14:2019 / A2:2019 / A15:2021

EN 60335-2-15:2016 / A11:2018

EN 62233: 2008 / AC: 2008

EN 55014-1:2017 / A11:2020

EN 55014-2:1997 / A1:2001 / A2:2008 / AC:1997

EN 61000-3-2: 2014 - EN 61000-3-3:2013

L'incarico di costituire e conservare il fascicolo tecnico è affidato alla Rocket Milano srl. in Via E. Curiel, 13 - 20060 LISCATE (MI) - ITALIA.

The Rocket Milano srl, Via E. Curiel, 13 - 20060 LISCATE (MI) - ITALY is responsible for establishing and maintaining the technical file.

La tâche de constituer et de conserver le dossier technique est confiée à la Rocket Milano srl in Via E. Curiel, 13 - 20060 LISCATE (MI) - ITALIE

Die Aufgabe der Einrichtung und Aufrechterhaltung des technischen Unterlagen anvertraut ist, die Rocket Milano srl in Via E. Curiel, 13 - 20060 LISCATE (MI) - ITALIEN

La responsabilidad de elaborar y conservar el expediente técnico corresponde alla Rocket Milano srl in Via E. Curiel, 13 - 20060 LISCATE (MI) - ITALIA

A responsabilidade de criar e guardar o fascículo técnico é confiada à la Rocket Milano srl in Via E. Curiel, 13 - 20060 LISCATE (MI) - ITALIA

La presente dichiarazione perde la sua validità nel caso in cui l'apparecchio venga modificato senza espressa autorizzazione del costruttore oppure se installato o utilizzato in modo non conforme a quanto indicato nel manuale d'uso e nelle istruzioni.

This declaration is null and void if the machine is modified without the express authorization of the manufacturer or if improperly installed and used in a way that does not comply with indications in the users' manual and the instructions

La présente déclaration sera considérée comme nulle et non avenue si l'appareil est modifié sans l'autorisation du fabricant ou si l'appareil est installé ou utilisé de façon non conforme à ce qui est indiqué dans le manuel d'utilisation et d'installation

Die vorliegende Konformitäts- erklärung verliert ihre Gültigkeit, falls das Gerät ohne ausdrückliche Genehmigung des Herstellers modifiziert werden sollte oder falls es nicht gemäß den im Bedienungs- und Wartungshandbuch aufgeführten

La presente declaración pierde su validez en el caso de que el aparato sea modificado sin expresa autorización del constructor, o bien si ha sido instalado o utilizado de forma no conforme a lo indicado en el manual de uso y en las instrucciones

A presente declaração deixa de ter validade no caso em que o aparelho seja modificado sem autorização do construtor ou se instalado ou utilizado de maneira não conforme ao indicado no manual de uso e nas instruções

Data di emissione - Date of Issue

Date d'émission - Ausstellungsdatum

Fecha de emisión - Data de emissão







Liscate

20 - 12 - 2022



CEO
Daniele Berenbruch

CONTENTS

	1 INTRODUCTION	40
	1.1 <i>SYMBOLS AND TERMINOLOGY USED IN THE MANUAL</i>	40
	1.2 <i>GENERAL INFORMATION</i>	41
	1.3 <i>SAFETY WARNINGS</i>	42
	2 UNPACKING	46
	2.1 <i>CONTENTS OF THE PACKAGING</i>	46
	3 DESCRIPTION OF THE MACHINE	47
	3.1 <i>INTENDED USE</i>	47
	3.2 <i>TECHNICAL SPECIFICATIONS</i>	48
	3.3 <i>MAIN PARTS MOD. APPARTAMENTO</i>	49
	3.4 <i>MAIN PARTS MOD. APARTAMENTO TCA</i>	50
	3.5 <i>ACCESSORIES</i>	51
	3.6 <i>TECHNICAL DATA</i>	51
	4 INSTALLATION	52
	4.1 <i>FILLING THE WATER TANK</i>	52
	4.2 <i>ELECTRICAL POWER SUPPLY</i>	53
	5 START-UP	54
	6 MACHINE OPERATION	55
	6.1 <i>COFFEE PREPARATION</i>	56
	6.2 <i>STEAM DISPENSING</i>	57
	6.3 <i>WATER DISPENSING</i>	58
	6.4 <i>ECO MODE</i>	58



7	PROGRAMMING (<i>APPARTAMENTO TCA only</i>)	59
	7.1 ACCESS TO PROGRAMMING	59
	7.2 PROGRAMMING PARAMETERS	60
	7.3 SAVING PROGRAMMING PARAMETERS	60
	7.4 CHANGING THE STATUS OF A PARAMETER	60
	7.5 PARAMETER RESET (<i>Factory Reset</i>).....	61



8	MAINTENANCE	62
	8.1 CLEANING THE STEAM WAND.....	62
	8.2 CLEANING THE DISPENSING HEAD	62
	8.3 CLEANING THE PORTAFILTER.....	64
	8.4 CLEANING THE WATER TANK	64
	8.5 CLEANING THE DRIP TRAY.....	65
	8.6 DESCALING	65
	8.7 BOILER WATER REPLACEMENT.....	66



9	ALARMS AND FAULTS	66
	9.1 ALARMS	66
	9.2 TROUBLESHOOTING	67
	9.3 INACTIVITY	69



10	DISPOSAL	69
-----------	-----------------------	----

1 - INTRODUCTION



BEFORE PERFORMING ANY OPERATION ON THE MACHINE, THE USER MUST CAREFULLY READ THE INSTRUCTIONS CONTAINED IN THIS PUBLICATION AND FOLLOW THEM THROUGHOUT THE INTERVENTIONS. IF IN DOUBT ON THE CORRECT INTERPRETATION OF THE INSTRUCTIONS, CONTACT OUR ASSISTANCE SERVICE FOR THE NECESSARY CLARIFICATIONS.

1.1 Symbols and terminology used in the manual



DANGER: this symbol indicates information or procedures which, if not carefully followed, may cause serious personal injuries. Potential source of injury or harm to health.



CAUTION

The instructions accompanied by this symbol contain information, requirements or procedures, which can cause damage or malfunctions, if not carried out correctly.



INFORMATION

The guidelines indicating this symbol contain information on particularly important topics and failure to comply with them may render the warranty null and void.



CAREFULLY READ the instruction manual before commissioning.



CAUTION: machine connected to the electrical mains!



Disconnect the power supply before performing any maintenance.



CAUTION: hot contact parts!



Wear protective gloves.



OPERATOR: this symbol indicates information or procedures concerning the user of the machine. Procedures within the competence of the person in charge of machine operation, use and routine maintenance.



QUALIFIED TECHNICIAN: this symbol indicates information or procedures regarding special maintenance (electrical/mechanical) for a qualified person authorised by the manufacturer

1.2 General information

This manual is an essential part of the **APPARTAMENTO** product; therefore, it is crucial that you read the enclosed warnings and precautions carefully before operating the machine. In particular, pay attention to the safety instructions during installation, commissioning, use and cleaning. Please keep this user manual in a safe location where it may be available to all users of the machine.



The coffee machine description provided below is of a general nature and may, therefore, not include all details on the various components.

The official language chosen by the manufacturer is Italian.

This manual reflects the state of the machine at the time of supply. **APPARTAMENTO** reserves the right to make, at any time, all the changes it deems appropriate to mass production and update the related manuals without the obligation to update previous production and manuals, as well as inform users of previously supplied machines.



CAUTION


THE MANUFACTURER SHALL NOT BE LIABLE FOR ANY DAMAGE CAUSED TO PEOPLE OR PROPERTY DUE TO:

- Improper use of the machine.
- Use by unsuitable personnel (unauthorised and/or untrained).
- Power supply defects.
- Lack of maintenance on machine components.
- Changes to the machine not authorised by the manufacturer.
- Use of non-original spare parts.
- Replacement of components supplied with the machine with other components having different technical specifications from those in the project.
- Failure to comply with these instructions.
- Failure to comply with the safety regulations.

TRANSPORT AND HANDLING



When handling the machine, take the necessary precautions to prevent it from falling, damaging people, animals and things, as well as the machine itself. Do not carry out this operation by yourself. It is recommended to have two people handle the appliance.

When handling the machine in the packaging, be sure to follow the wording “**THIS WAY UP**” (identified by the symbol ) on the packaging.

Do not overturn the machine during handling. Handle with care.

The manufacturer cannot be held responsible for damage caused by incorrect handling or by not complying with the indications provided.

1.3 Safety warnings**IMPORTANT PRECAUTIONS**

1. Read all instructions
2. Do not leave the packing elements (plastic bags, expanded polystyrene, nails, cardboard, etc.) within the reach of children, as these elements are potential sources of danger.
3. Install the machine on a flat, water repellent surface (laminated, steel, ceramic, etc.) away from heat sources (oven, cooking stove, fireplace, etc.) and in conditions in which the temperature cannot drop below 5°C. Keep warm.
4. Do not use outdoors.
5. For domestic use only
6. Do not leave the machine exposed to environmental elements or place it in damp rooms.
7. Do not obstruct the grids and do not cover with cloths, etc.
8. Keep the packed machine in a dry place, not exposed to environmental elements and in conditions in which the temperature does not go below 5°C.
9. Do not place heavy items on the package.
10. In an emergency, such as fire, unusual noise, overheating, etc., take immediate action by disconnecting the power.
11. The installation and repair must conform to the codes and local electrical safety regulations.
12. Do not let the power cable hang over the edge of the table or counter or touch hot surfaces.
13. The **APPARTAMENTO** machine must be installed after reading and understanding this publication
14. This machine is only safe when it has been correctly connected

to an efficient earthing system.

15. Always connect the plug to the appliance first, then plug the power cable into the wall socket. To disconnect, set the switch to **OFF**, then remove the plug from the wall socket.
16. Check to see that the data on the rating plate corresponds to that of the main electrical mains to which the machine will be connected. Before connecting the machine to the electrical mains, make sure that the voltage, frequency and power of the machine correspond to those of the local electrical mains. The electrical data are indicated on the machine rating plate.
17. We do not recommend the use of accessories such as adaptors, multiboards or extension cords not recommended by the appliance manufacturer as they may cause injuries, fires or electric shocks.
18. Do not use this machine if the cable, plug or any other part is damaged or if the machine malfunctions. Return the machine to the nearest authorised service facility for examination, repair or adjustment. **CAUTION:** The power cable must not be replaced by the user.
19. This machine has been designed for the sole purpose of producing coffee and dispensing steam and hot water for beverages. All other uses are inappropriate and dangerous. The manufacturer shall not be held responsible for any damage caused by inappropriate use.
20. To protect against electric shocks when using any electrical appliance including the **APPARTAMENTO** machine:
 - a. Do not immerse the machine itself, cable and plugs in water or other liquid and do not let the machine's internal parts get in contact with liquid.
 - b. Make sure the power cable is not stretched or pulled.
 - c. Do not use the machine with wet hands or feet.
 - d. Do not allow children or untrained persons to use the machine.
 - e. Do not operate the machine with bare feet.
 - f. Place a circuit breaker at the electrical mains feeding the machine.
 - g. Do not spill liquids on top of the machine.

- NE** h. The machine should not be exposed to elements such as sunlight, rain, snow, extreme temperatures etc.
- i. Avoid any spillage of water on electrical connections.
- 21.** Always use **ROCKET** certified and manufactured spare parts and accessories.
- 22.** Before carrying out any cleaning or maintenance, switch off the machine using the machine's power switch, disconnect the machine from the mains and wait for its temperature to drop.
- 23.** This appliance is intended for domestic use.
- 24.** If the machine operates in a faulty manner or stops working, turn it off immediately and disconnect it from the electrical supply. Do not attempt to repair it but contact an authorized and qualified **APPARTAMENTO** technician. Any repair must be performed by the manufacturer or by an authorized dealer using only original parts.
- 25.** When the machine is not used for long periods of time it must be stored at a temperature above zero (0°C / 32°F). This will prevent the hydraulic system from freezing, which could damage the internal pipes and boiler.
- 26.** The machine must be used with drinking water. Use a water softener if water from the local mains has a high mineral content. A build-up of mineral deposit may restrict the flow of water within the hydraulic systems causing damage to the machine and risking personal injuries. Conversely, highly "pure" waters may interfere with the electronic signals read by the machine for both boiler level and water tank level indications. Use filtered water.
- 27.** The appliance must not be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have received supervision or instruction concerning use of the appliance from a person responsible for their safety.
- 28.** Keep the appliance and relevant cable out of reach of children.
- 29.** Children must not play with the appliance.
- 30.** Do not pull the power cable to disconnect the appliance from the power supply.
- 31.** To ensure correct operation and efficiency of the machine, it is required to follow the manufacturer's instructions, carrying out

cleaning and routine maintenance operations.

- 32.** During machine operation some parts reach high temperatures, such as the dispensing units, the portafilters and the steam wands (indicate the photo with the figures?). Pay attention not to touch or put your hands under these parts when using them, to prevent scalds or burns. Always use appropriate knobs and handles for operation.
- 33** Install the portafilter by inserting it into the head of the unit and turning the handle from left to right. The portafilter is inserted correctly once it is firmly inside the head of the unit and the handle is positioned at 90 degrees to the front of the machine
- 34** Never remove (disengage/release) the portafilter while dispensing coffee. Burns could occur if the portafilter is removed during dispensing cycles.
- 35** Pay close attention to the surfaces of the heating elements as they are subject to residual heat even after use.
- 36** Do not use the device for any other use than its intended one.
- 37** The coffee machine must not be stored in a closed place (cabinet, etc.) when in use.
- 38** This appliance is intended for use in domestic or small catering environments such as:
 - a. Kitchen areas for staff in shops, offices and other workplaces.
 - b. Agritourism establishments with a common room for kitchen use.
 - c. By customers in hotels, motels and other residential environments.
 - d. Bed and breakfasts and the like.

KEEP THESE INSTRUCTIONS

2 - UNPACKING




Before proceeding, the machine installation personnel must read these instructions and, in particular, the previous sections regarding general information and safety requirements.



2.1 Contents of the packaging


The machine is supplied fully assembled (with the exception of the accessories contained in the special boxes - fig. 2.1).



fig_2.1



The machine data are indicated on the “CE” marking plate applied under the machine (fig. 2.2).



ROCKET MILANO S.r.l.

SERIE:

MODEL:



MADE IN ITALY

fig_2.2

The packed machine must be protected in a sheltered and moisture-free premises until it is installed in a suitable environment. After removing the packaging, it is required to verify that the various components are in perfect condition and that there are no traces of tampering, damaged parts, etc. It will also be necessary to check that the machine is complete with all its parts, any accessories and technical documentation as per the transport documentation.



CAUTION! Before proceeding with the installation, in case anomalies are found in the checks on delivery, report the findings to the manufacturer.



The packaging elements (plastic bags, expanded polystyrene, nails, cartons, etc...) must not be left within the reach of children as they are potential sources of danger. These elements must be disposed of in accordance with the local regulations in force



3 - DESCRIPTION OF THE MACHINE

3.1 Intended use



The machine has been designed and built to be used to prepare espresso coffee and hot drinks.

Any other use is to be considered unsuitable and therefore dangerous.





The manufacturer cannot be held responsible for any damage caused to people or things due to unsuitable, erroneous or irrational use of the machine

The operator must always follow the indications contained in this manual. In the case of a failure or if the machine is not working properly, switch it off and do not attempt any direct repair. Contact the service centre.



mod. APPARTAMENTO

fig_3.1




mod. APPARTAMENTO TCA



3.2 Technical specifications

mod. APPARTAMENTO	MOD. APPARTAMENTO TCA
<ul style="list-style-type: none"> ■ Eco mode available (see par. 6.3) 	<ul style="list-style-type: none"> ■ Eco mode available via software (see par. 6.4)
<ul style="list-style-type: none"> ■ Boiler capacity: 1,8 litres 	<ul style="list-style-type: none"> ■ Boiler capacity: 1,8 litres
<ul style="list-style-type: none"> ■ Voltage (<i>version A</i>): 220-240V 50/60 Hz <i>for EC versions</i> ■ Voltage (<i>version B</i>): 115V - 60 Hz <i>for USA/CAN versions</i> 	<ul style="list-style-type: none"> ■ Voltage (<i>version A</i>): 220-240V 50/60 Hz <i>for EC versions</i> ■ Voltage (<i>version B</i>): 115V - 60 Hz <i>for USA/CAN versions</i>
<ul style="list-style-type: none"> ■ Boiler heating element: 1200 W 	<ul style="list-style-type: none"> ■ Boiler heating element: 1200 W
<ul style="list-style-type: none"> ■ Removable water tank: 1,9 L 	<ul style="list-style-type: none"> ■ Removable water tank: 1,9 L
<ul style="list-style-type: none"> ■ Dimensions and weight (fig_3.1) Width: 274 mm Depth: 431 mm Height: 362 mm Weight: 22 kg 	<ul style="list-style-type: none"> ■ Dimensions and weight (fig_3.1) Width: 274 mm Depth: 448 mm Height: 364 mm Weight: 25 kg

3.3 Main parts mod. APPARTAMENTO




fig_3.2

1. **ON / OFF:**
"O" = OFF
"I" = ON
2. Control indicators
3. Coffee dispensing knob
4. Steam dispensing knob
5. Steam wand
6. Pressure gauge
7. Portafilter
8. Water tank holder chamber
9. Cup warmer
10. Cup warmer grid + tray
11. Eco Mode button
12. Hot water dispensing knob
13. Hot water wand
14. Wand kit handle



EN

3.4 Main parts mod. APPARTAMENTO TCA



fig_3.3


- | | |
|--|---|
| <ol style="list-style-type: none"> 1. ON / OFF:
"O" = OFF
"I" = ON 2. Control indicators 3. Coffee dispensing control lever 4. Steam dispensing knob 5. Steam wand 6. Pressure gauge 7. Portafilter | <ol style="list-style-type: none"> 8. Water tank holder chamber 9. Cup warmer 10. Cup warmer grid + tray 11. Hot water dispensing knob 12. Hot water wand 13. Wand kit handle |
|--|---|



3.5 Accessories

The machine is supplied complete with a wide series of accessories (fig._3.4). The first box contains the following parts and accessories:

1. Portafilter - single
2. Portafilter - double
3. Tamper
4. Blind filter
5. Dispensing head cleaning brush.
6. Display window (only for APPARTAMENTO)
7. Cup frame.
8. Instruction Manual
9. Microfiber cloth



fig_3.4

3.6 Technical data

Voltage

- Please refer to the technical data plate on the machine.

Power

- Please refer to the technical data plate on the machine.

Temperature

- The machine must not be operated with temperatures under 5°C and over 36°C.

Water

- The machine must be operated with soft, clean drinking water. If the local water mains has a high mineral content, use a water softener. The water hardness must be between 4 - 7 °f (French) / 2 - 4 °d (German). A build-up of mineral deposit may restrict the flow of water within the hydraulic systems causing damage to the machine and risking personal injuries.

Boiler capacity


- 1.8 litres

4 - INSTALLATION

The machine must only be installed in places where it is easy to use and access. The support surface must be levelled, dry, smooth, stable and at such a height that the base is at least 100/105 cm approx. above the ground. (fig._4.1)

Do not use or install where water jets are used.


In order to ensure normal operation, the



fig_4.1

machine must be installed in areas where the room temperature is between +5°C and +36°C and humidity does not exceed 70%.

Ensure that there is an open area of at least **10 cm** on each side and behind the machine to allow adequate ventilation and facilitate its use and the performance of any maintenance operations. (fig._4.2)



fig_4.2



If the machine is wet or very damp, wait until it is completely dry before installing or using it.

4.1 Filling the water tank



Make sure to use water with a degree of hardness suitable for this type of machine (see par. 3.6 page 51)


The machine has to operate with clean soft drinking water. Never attempt to operate the machine with water of a hardness other than that specified in paragraph 3.6.

Lift the tank chamber cover (1 fig. 4.4) and fill with water up to the "MAX" level indicated (about 1,9 L). The manufacturer recommends inserting a softener bag (2) in the water tank.

fig_4.3



Pay attention to only pour water into the water tank, use a funnel if required. (to remove the tank for cleaning see chap. Maintenance page 62). Reposition the cover of the water tank chamber.



fig_4.3



Check the package for validity of the softener used (quantity of litres)


4.2 Electrical power supply



Before connecting the machine ensure that the identification label data comply with those of the local electric mains.

The earthing system must be carried out in accordance with the provisions of current legislation.

Connect the power cable. (fig_4.4)



fig_4.4



Place any excess cable on the worktop, so that it cannot be pulled by children or cause tripping.



CAUTION:

If the power cable is damaged it is to be replaced by the manufacturer or by their technical assistance service or by a person with equivalent qualification, in order to prevent any risks.





5 - START-UP

We assume the machine has been installed correctly.

- Make sure that the lever is positioned vertically (**OFF** - fig._5.6)
- Turn the On/Off switch (1 - fig._5.1) from position “O” to “I”. After switching it on you get:


APPARTAMENTO model: the indicator light (2 - fig._5.1) lights up steady green.

APPARTAMENTO TCA model: the indicator light (2) is blue when switched on and turns white when the machine is running.



fig_5.1

- Open the steam knob (3 - fig._5.2) to start filling the boiler with water.




fig_5.2

APPARTAMENTO model: you should hear the sound of the pump.

APPARTAMENTO TCA model: you should hear the sound of the pump and the indicator light (2 - fig._5.1) will flash with a BLUE light.

When the boiler is correctly filled with water, the pump stops (the noise stops).

- Then close the steam knob.



fig_5.3


The boiler heating begins.

Wait for the boiler pressure gauge (4 - fig._5.3) to indicate approximately **1 bar**.

- Open the steam knob (3 - fig._5.4) for 5 seconds to allow some steam to come out.



This operation is highly important as it eliminates any vacuum inside the boiler which may cause milk to be sucked into the boiler once steam dispensing has begun. Close the



fig_5.4



steam knob again.

- Wait for the boiler pressure gauge (4 - fig. 5.3) to reach **1 bar** again.
- Fully raise the coffee dispensing control lever (4 - fig. 5.5). Drain a cup of hot water from the infuser unit head (5).




fig. 5.5

This operation must only be performed once at first use.

- Lower the coffee dispensing lever completely to stop the water flow (fig. 5.6)




fig. 5.6

- The machine is now ready for use

Allow a heating time of 15-18 minutes so that the head of the unit is fully heated: the quality of the espresso will be greatly improved with a hot unit and portafilter inserted.



6 - MACHINE OPERATION



Make sure that the machine is ready for full safety operation as described in the previous chapters



CAUTION:
The portafilter unit heats up when the machine is ready. Pay attention



It is recommended to perform a first water dispensing without coffee with a new portafilter or on first use. This operation is recommended to eliminate any processing residues

1. Install the portafilter by inserting it into the unit head and rotate the portafilter handle from left to right. The portafilter is inserted properly once it is firmly inside the unit head and the handle is positioned at 90 degrees from the front of the machine (fig. 6.1)





fig. 6.1

2. Now raise the coffee dispensing control lever to start the water flow through the portafilter. (fig. 6.2)



EN




fig_6.2

3. It is important to leave the portafilter hooked in the unit head when not in use. The portafilter must remain heated for an optimal brew process. It will also prevent the seal inside the unit head from drying out prematurely.


6.1 Coffee preparation

1. Choose the portafilter for the preparation of one or two cups in a single dispensing (fig._6.3).




fig_6.3

2. Fill with ground coffee and press (fig._6.4), removing any coffee residues on the edge of the filter



fig_6.4

3. Hook the portafilter to the dispensing unit and place the cup(s) under the coffee dispensing spout.



fig_6.5

4. Start dispensing by raising the coffee dispensing control lever. To stop dispensing, lower the lever again. On the TCA model, the LED flashes white during the dispensing phase and returns to steady when dispensing is finished (fig._6.5).





The maximum duration of a single dispensing is 100 seconds. After this time, dispensing stops automatically even if the user has not closed the lever.



Dispensing has priority over filling: if dispensing is requested while the machine is filling water, filling is temporarily suspended and dispensing begins regularly. It is possible to dispense even when the boiler level has not yet been reached.

5. Remove the portafilter to empty and clean it and then hook it up again (fig_6.6)




fig_6.6

6.2 Steam dispensing

With the machine switched on and pressure gauge in pressure (see chap. 5 p. 22) steam can be dispensed from the steam wand.

Take a jug and place the steam wand into the drink and open the steam tap (3 - fig_6.7)



fig_6.7


Once the desired dispensing is complete, close the tap and remove the jug. Clean the wand with a damp cloth.



Dispense steam for a few seconds and then clean again with a damp cloth (fig_6.8)



EN



fig_6.8



CAUTION:
The jet of steam may cause burns. To avoid burns, use the small plastic handle to move the steam wand.



For best results:
store milk at $\leq 5^{\circ}\text{C}$ ($\leq 41^{\circ}\text{F}$)


6.3 Water dispensing

To dispense hot water, open the corresponding tap (1 fig_6.9) and release the required amount of water into a cup or container. To stop the hot water supply, close the tap itself.

CAUTION:



the water is very hot.
Take care to avoid possible burns



fig_6.9

6.4 ECO mode


With ECO mode enabled:

The machine **APPARTAMENTO** goes into standby mode after 60 minutes of inactivity.

The machine, **APPARTAMENTO TCA**, goes into standby after 30 minutes.

When the machine is in standby, all heaters are off and delivery is not possible. The machine exits standby by operating the dispensing lever.

On the **APPARTAMENTO** model, the **ECO-ON** mode is activated by pressing the button below the machine (fig_6.10), while on the **APPARTAMENTO TCA** model it is activated during programming.



fig_6.10




The machine is supplied from the factory with the ECO mode activated.

7 - PROGRAMMING (APPARTAMENTO TCA only)



The machine, which is being tested, has already undergone basic programming and is therefore ready for use.

The user can vary certain machine parameters by entering the 'programming' mode and operating the coffee dispensing lever (1 - fig_7.1) and indicator light. (2)









fig_7.1

The user-modifiable parameters are as follows:

- 1. Boiler pressure (red).
- 2. ECO MODE of the machine (green).


7.1 Access to programming

To access programming, the user must proceed as follows:

	<p>1. Turn off the machine by turning the selector switch to the OFF position</p>
	<p>2. Raising the coffee dispensing lever</p>
	<p>3. Switch on the machine</p>
<p>YELLOW LIGHT</p> 	<p>4. When the indicator light changes colour (yellow) lower the dispensing lever 2 (within 3 seconds). The machine is now in programming mode</p>
	<p>5. To switch from one parameter to another, confirm the previous one by holding the lever up for 3 seconds (waiting for the light to go on) and only then lower it.</p>
	<p>6. Each parameter is identified by an indicator colour and its number of flashes determines the setting value as described in the table below</p>

**7.2 Programming parameters**

Editable parameter	LED colour	Status selectable	Command
Boiler pressure adjustment	RED	Low	No. 1 flash
		Medium (default)	No. 2 flashes
		High	No. 3 flashes
		Very high	No. 4 flashes
Stand-By	GREEN	Not active	No. 1 flash
		Active (after 30 minutes)	No. 2 flashes

7.3 Saving a programming parameter

1. After identifying the number of flashes corresponding to a certain parameter, lift the dispensing lever, holding it in position for 3 seconds, until the light remains steady.




2. Confirmation that the parameter has been saved is confirmed by the steady LED light. Lower the dispensing lever to move to the next parameter.

Example of MEDIUM BOILER PRESSURE setting.

- 1 Enter the programming mode, the light is flashing once in RED colour indicating the LOW Boiler Pressure setting.
- 2 Raise and lower the lever, the RED light will flash twice, indicating the MEDIUM Boiler Pressure setting.
- 3 Keep the dispensing lever raised until the steady RED light is displayed.
- 4 Steady RED light confirms that the parameter has been saved. Lower the lever to move on to the next parameter.

To exit programming, restart the machine by pressing the main switch.





7.4 Changing the status of a parameter

1. To switch between states of a parameter (number of flashes) quickly (within 3 seconds) raise and lower the dispensing lever.

7.5 Parameter reset (Factory Reset)

By means of this procedure it is possible to delete all set parameters and restore the original factory setting. This function should be used in those cases where errors or unwanted variations have been introduced, choosing to reset everything and return to the initial conditions.

This procedure is carried out as described below.

	<p>1. From Machine OFF, switch the machine ON with the unit lever in the dispensing position (contact closed); the machine does not perform any action but waits for a few seconds from the operator.</p>		<p>3. If, within 3 seconds of the green light coming on, the lever is returned to rest, a factory parameter reset (default) is implemented, indicated by the permanence of the steady green light. If, on the other hand, the lever is left in the dispensing position, after the 3-second time limit has elapsed, the green indicator light will remain flashing without performing a parameter reset, waiting for a Poweroff.</p>
	<p>2. Keep the lever in the dispensing position. After a few seconds, if the lever has always remained in the same position, the machine turns on the yellow light (as for normal programming) for 5 seconds until the flashing green light appears.</p>		<p>4. Switch off the machine and if the reset procedure is not implemented, return the lever to the home position anyway.</p>



EN

8 - MAINTENANCE



Maintenance operations must be carried out when the machine is off and cold. Some particular operations must be performed when the machine is operating.

Do not clean the machine by using metal or abrasive devices, such as steel wool, metal brushes, needles, etc. or general detergents (alcohol, solvents, etc.)

When necessary, use special detergents for coffee machines that can be purchased in specialised service centres.

Keeping your machine clean will prolong its life and produce better espresso beverages.


8.1 Cleaning the steam wand

1. Clean the steam wand after every use by wiping with a damp cloth. Turn the steam wand on to release condensation and milk residue.
2. If the steam jets become clogged with the powdered milk, unscrew the nozzle and unlock/clean with a paper clip (fig._8.1).

8.2 Cleaning the dispensing head

BACKFLUSHING


1. Remove the filter basket from the portafilter and fit the blind filter (A - fig_8.2).
2. While the brew water is flowing loosely insert the portafilter into the unit head, rotating the portafilter back and forth (B - fig_8.2). Keep emptying the blind basket of hot water until the water runs clear.
3. Backflush the unit head every day.



fig_8.1

DISPENSING UNIT HEAD


1. Every week, after backflushing, add a small amount of espresso cleaning detergent to the blind basket. Dissolve the detergent in hot water and insert the portafilter into the unit head. This detergent is available from every authorised dealer.
2. Open and close the unit dispensing for about 10 seconds. Repeat several times.



fig_8.2


**REMOVING THE SPRAYER, DIFFUSER AND HEAD GASKET**

1. Using a small slotted screwdriver, pry the inner edge of the sprayer (1) and remove it together with the gasket (2) as shown in fig_8.3.
2. With the same screwdriver, unscrew the diffuser (3) from the head (fig_8.4).




fig_8.3

3. Scrub the inside of the unit head with the unit cleaning brush supplied (fig_8.5).



fig_8.4


4. Using a damp cloth, clean the area where the portafilter connects to the unit head.



fig_8.5

5. Soak the metal parts that have been removed in a solution made from 2 teaspoons of espresso cleaning detergent and hot water. Soak for 10 minutes. Rinse thoroughly, clean and reassemble.
6. Screw the head diffuser back on respecting the order shown in figure 8.6. Lastly, insert and hook the sprayer with its gasket

If the elements of the head are worn or damaged, replace them. These items are consumables. Contact your authorised **ROCKET dealer**.




fig_8.6



8.3 Cleaning the portafilter

PORTAFILTER


1. Remove the filter basket from the portafilter handle using a small screwdriver or the under-side of the blind basket (fig. 8.7).
2. Wipe the inside of the basket and portafilter clean with a damp cloth.
3. If the coffee oils have built up, soak the metal end of the portafilter and basket in the same detergent solution as the brass shower foil described above.
4. Rinse thoroughly, dry and reassemble.



fig_8.7

8.4 Cleaning the water tank

Periodically remove and clean the water tank with warm soapy water. To remove the tank, lift the cover (1 - fig. 8.8) and extract the tank (2) using the handle: perform an upward movement.



fig_8.8


When reinserting the tank, be sure to firmly press down so that the bottom tank tap is fully engaged.

Use fresh, filtered water to fill the tank. Do not use distilled water (see par. 3.6 page 51).



8.5 Cleaning the drip tray


1. Remove the grid and the tray and wash with warm soapy water. Rinse and dry. (fig._8.9)



fig_8.9

2. First reassemble the tray, making sure that it is placed and inserted (with horizontal movement) until it reaches the “stop”, after “hooking” has taken place (a magnetic click at the end of the stroke should be heard - fig._8.10)

CAUTION: If the tray is only left resting and not fully inserted, the water coming out of the group and from the drain flows into the front part of the base and could come out of the machine.



fig_8.10

8.6 Descaling



1. **ROCKET** does not recommend removing limescale from the espresso machine. **Contact an authorised ROCKET centre for descaling.**



2. Many of the chemicals used to descale espresso machines are particularly aggressive. These chemicals can cause internal corrosion of hard metals used in the construction of the machine.



3. Additionally, it is very difficult to remove all the descaling solution from the machine once the procedure is completed.
4. Check the quality of the water you use in the machine, always using filtered water. Distilled water may lack the necessary conductivity required for various electronic functions needed in the operation of the machine.



8.7 Boiler water replacement

It is recommended to change the water in the boiler periodically, at least once a month or, in the case of frequent use, every fortnight. Read all the steps described below carefully before performing the operation; if in doubt, contact the **ROCKET** service centre for clarification and support.




IMPORTANT:

This operation must be carried out with the machine just turned off with hot water and the boiler pressurised (fig._5.4).



To carry out the boiler water change procedure, simply open the water nozzle (fig._8.11), repeating the operation twice.



fig_8.11

9 - ALARMS AND FAULTS

9.1 Alarms

The machine has a colour LED indicator on the front panel. During normal operation (dispensing and standby) the LED is fixed white.

Other conditions are signalled by different combinations of colours and flashes:

mod. APPARTAMENTO TCA		
Alarm	Cause	Solution
Flashing MAGENTA light	Alarm empty tank	Fill the tank with water
GREEN flashing light	ECO mode (stand-by) active	Raise and lower the dispensing lever to re-activate the machine
Flashing YELLOW light	DISPENSING timeout	Lower the dispensing lever, if the problem persists contact ROCKET Service
RED light with 2 flashes	Boiler heating timeout	Switch the machine off and on again if the problem persists contact ROCKET Service



RED light with 3 flashes	Boiler level timeout	Contact ROCKET Service
RED light with 4 flashes	Pressure sensor or boiler NTC failure	Reset the parameters (see par. 7.5), if the problem persists please contact ROCKET Service

APPARTAMENTO model		
Alarm	Cause	Solution
Indicator light 0.5" ON/ 0.5" OFF x 3 times and 2" OFF	Boiler load	Contact ROCKET Service
Indicator light 3" ON + 3" OFF	Dispensing	Lower the dispensing lever, if the problem persists contact ROCKET Service
Indicator light 0.5" ON + 4.5" OFF	Economy	Raise and lower the lever
Indicator light 0.5" ON + 0.5" OFF	Empty tank	Filling the tank

9.2 Troubleshooting

The machine does not start

- Check that the main switch is in the **ON** position.
- Check that the plug is inserted.

No coffee or steam dispensing

- Check that water is present in the tank .
- Check that the coffee and steam controls have been activated before dispensing .

The machine does not heat

- Contact the technical assistance

Irregular steam dispensing

- Make sure the sprayer holes are clean

Extraction is too slow

- Check that the filter basket is not too full (too much coffee).
- Check that the grind is not too fine.
- Check that the shower foil is not blocked: it may need to be back-flushed or be removed and cleaned
- Check the spout of the handle is not blocked. If it is dirty with rancid coffee oil, it will need to be soaked in an espresso head cleaning solution.

Water leaking from the portafilter

- Check the head gaskets. If visibly worn, they will need to be replaced.



- Ensure the portafilters are kept in place on the head whenever the machine is not in use, as this will help to protect the seals.

Espresso is too cold

- Check that the cups are hot enough. Cups can be heated by pouring hot water into them, and then discarding it, before starting the extraction.
- Too much water may have been drawn from the unit head. Let the machine rest and limit the amount of water drawn from it between extractions to ensure the machine remains at temperature.

Water underneath the machine

- Check that the tray is inserted correctly
- Check that the drain tray has been emptied

The machine appears to be off but the switch is in the ON position

- Check that the **Eco mode** function is active by operating the coffee control (see par. 6.4).
- Switch the machine off and on again from the main switch (see 1 - fig. 3.2 - 3.3)

Espresso tastes bitter

- Extraction may be too slow. Check that the grinding is not too fine. Correct the grinding and make it coarser.
- The machine may be dirty. Backflush again and clean the unit head. Clean the portafilters and filter baskets.

Espresso tastes sour

- Extraction may be too fast. Check that the grinding is not too coarse. Correct the grinding and make it finer.

Espresso is watery and thin

- Extraction may be too fast. If so, the cream will be pale. Check that the grinding is not too coarse. Correct the grinding and make it finer.

Espresso is bubbly

- The water in the machine may be too hot. Let some water flow from the unit head. Perform another extraction.
- The coffee may be too fresh.

Low or no pressure from the steam wand

- It may be due to excessive use of the unit head. Excessive use of the steam wand. Give the machine time to recover pressure.
- The steam wand may be clogged with dry milk. Remove the nozzle and clean it as indicated in point 7.1.

Milk is thin and bubbly

- Ensure the milk is diluted gradually. If air is introduced too quickly, large bubbles will form.
- Make sure that the steam comes out with the right pressure and that there are no blocked nozzles.
- It may be due to using reheated milk. Try again with fresh milk.



For any type of problem not specifically indicated on this page, turn off the machine by pressing the main switch, disconnect the plug and contact our technical assistance.

9.3 Inactivity

For prolonged machine inactivity, it is required to carry out certain preventive operations:

- disconnect the machine electrically.
- unload all portafilters.
- wash all the parts in contact with food-stuffs.
- clean all the internal and external surfaces of the machine with a cloth.
- protect the outside with a cellophane film or bag.
- store in dry sheltered rooms with temperatures no lower than 1°C.

10 - DISPOSAL

Proceed with emptying the products and the water as described in the previous paragraph.



Caution! Check that machine disposal is performed with respect of environmental rules and according to the regulations in force

Information to the users

Pursuant to Legislative Decree 25 September 2007, no. 185 and Art. 13, Legislative Decree 25 July 2005, no. 151 "Implementation of Directives 2002/95/EC, 2002/96/EC and 2003/108/EC, on the restriction of the use of hazardous substances in electrical and electronic equipment, and on the disposal of waste".



The barred waste bin symbol on the equipment means that the product, at the end of its service life, must be disposed of separately from the other types of waste.

The user must therefore transport the equipment, at the end of its service life, to the appropriate separate collection centres for electronic/electro-technical waste products or return it to the dealer when purchasing a new equivalent equipment.

The appropriate separate collection and the following sending of the used equipment to recycling, treatment and eco-friendly disposal will help avoid negative effects on the environment as well as on health along with an easier recycling of the materials forming the equipment.

*Tutti i diritti riservati. Questo manuale non può essere riprodotto, in tutto o in parte, senza la preventiva autorizzazione scritta di **ROCKET MILANO s.r.l.***
ROCKET MILANO s.r.l. si riserva il diritto di apportare in qualsiasi momento le modifiche che riterrà necessarie.

*All rights reserved. This manual may not be reproduced, in whole or in part, without the prior written authorization of **ROCKET MILANO s.r.l.***
ROCKET MILANO s.r.l. reserves the right to make any changes it deems necessary at any time.

*Tous droits réservés. Ce manuel ne peut être reproduit, en tout ou en partie, sans l'autorisation écrite préalable de **ROCKET MILANO s.r.l.***
ROCKET MILANO s.r.l. se réserve le droit d'apporter à tout moment les modifications qu'elle considèrera nécessaires.

*Alle Rechte vorbehalten. Dieses Handbuch darf ohne die vorherige schriftliche Genehmigung von **ROCKET MILANO s.r.l.** weder ganz noch auszugsweise vervielfältigt werden.*
ROCKET MILANO s.r.l. behält sich das Recht vor, jederzeit die für notwendig erachteten Änderungen vorzunehmen.

*Todos los derechos reservados. Este manual no puede reproducirse, total o parcialmente, sin el permiso previo por escrito de **ROCKET MILANO s.r.l.***
ROCKET MILANO s.r.l. se reserva el derecho a realizar los cambios que considere necesarios en cualquier momento.

*Todos os direitos reservados. Este manual não pode ser reproduzido, no todo ou em parte, sem autorização prévia por escrito de: **ROCKET MILANO s.r.l.***
A ROCKET MILANO s.r.l. reserva-se o direito de fazer a qualquer momento as alterações que considere necessárias.

ROCKET[®]
ESPRESSO MILANO

ROCKET MILANO S.R.L.
Via Curiel 13, 20060 LISCATE (MI) Italy